




Accessories

Auxiliary Contacts

Description	Operator Position ⁽¹⁾			Term. No.	Contact Description	Connection Diagram ⁽²⁾	For Use With	Cat. No.
	OFF	ON	Tripped					
 Front-Mounted Auxiliary Contact • 1-pole or 2-pole • No additional space required • Only one per device	0	X	0	13-14	N.O. Aux		140M-C, D, F; 140U-D (UL489) only in combination with 140M-C-AFC	140M-C-AFA10
	X	0	X	11-12	N.C. Aux			140M-C-AFA01
 Front-Mounted Auxiliary Contact • 1-pole or 2-pole • No additional space required • Only one per device	0	X	0	13-14	N.O. Aux		140M-C, D, F; 140U-D (UL489) only in combination with 140M-C-AFC	140M-C-AFA11
	X	0	X	21-22	N.C. Aux			140M-C-AFA20
	0	X	0	13-14	N.O. Aux			140M-C-AFA20
	0	X	0	23-24	N.O. Aux			140M-C-AFA20
	X	0	X	11-12	N.C. Aux			140M-C-AFA02
	X	0	X	21-22	N.C. Aux			140M-C-AFA02
 Right Side-Mounted Auxiliary Contact • 2-pole • Adds 9 mm to the width of the device • Two per device	0	X	0	33-34	N.O. Aux		140M-C, D, F	140M-C-ASA20
	0	X	0	43-44	N.O. Aux			140M-C-ASA20
	X	0	X	31-32	N.C. Aux		140M-C, D, F	140M-C-ASA02
	X	0	X	41-42	N.C. Aux			140M-C-ASA02
	0	X	0	33-34	N.O. Aux		140M-C, D, F	140M-C-ASA11
	X	0	X	41-42	N.C. Aux			140M-C-ASA11

(1) X = Contact Closed; 0 = Contact Open

(2) Connection Diagram Reference:

