




## Accessories

## Mounting Adapters

	Description	Catalog Number
<b>M22-A</b>	Contact block mounting adapter. ①	<b>M22-A</b>
		
<b>M22-A4</b>	Contact block mounting adapter, four-position (for use with four-way pushbuttons, joysticks and four-position selector switches only). ①	<b>M22-A4</b>
		
<b>M22-LS</b>	Allows mounting of M22 pushbuttons to LS-Titan limit switch bodies (for the full LS-Titan catalog section, see <b>PG08301004E</b> ). ①	<b>M22-LS</b>
		

## Contact Blocks

M22-K10;



Mounting Location	Terminal Type	Contact Configuration ②	Package Qty.	Catalog Number
Front	Screw	NO	1	<b>M22-K10</b>
		NO	25	<b>M22-K10-B25</b>
		NO	100	<b>M22-K10-B100</b>
		NO, early-make	1	<b>M22-K10P</b>
		NC	1	<b>M22-K01</b>
		NC	25	<b>M22-K01-B25</b>
		NC	100	<b>M22-K01-B100</b>
		NC, late-break	1	<b>M22-K01D</b>
Base		NO	1	<b>M22-KC10</b>
		NO	25	<b>M22-KC10-B25</b>
		NO	100	<b>M22-KC10-B100</b>
		NC	1	<b>M22-KC01</b>
		NC	25	<b>M22-KC01-B25</b>
		NC	100	<b>M22-KC01-B100</b>
Front	Spring cage	NO	1	<b>M22-CK10</b>
		NC	1	<b>M22-CK01</b>
		NC, late-break	1	<b>M22-CK01D</b>
		2NO ③	1	<b>M22-CK20</b>
		2NC ③	1	<b>M22-CK02</b>
		NO-NC ③	1	<b>M22-CK11</b>
Base		NO	1	<b>M22-CKC10</b>
		NC	1	<b>M22-CKC01</b>

## Notes

- ① Included with each operator.
- ② All NC contact blocks are positively driven contact. ⊖
- ③ Not stackable.